Specifications :

- Turn off your solder iron and let it cool down for 15-20 minutes before cleaning the tip. This will allow you to clean the device as thoroughly as possible without risking bums. Clean the tip immediately after the solder iron to limit buildup over time. Place a sticky note near your workspace if you find yourself forgetting often to make cleaning the iron a priority.
- Used to clean off soldering iron tip
- Can be made of various materials
- Should be used every time before soldering a joint.

Note: Specifications are subject to change, Photos shown above are Indicative, Actual Product can Vary.

Follow Tescaglobal

worlddidac MEMBER