

**Specifications:-**

- Network Cable Tester Rj45
- Slow Automatic Grade, Mis Manual.
- Put Cables Into Both Main Tester And Remote Tester. The Lights Of The Main Tester Will Turn On Sequently Form 1 To G.
- Main Tester: 1-2-3-4-5-6-7-8-G
- Remote Tester: 1-2-3-4-5-6-7-8-G Rj45

*Note: Specifications are subject to change, Photos shown above are Indicative, Actual Product can Vary.*



Export Sales: +91-9829132777  
India Sales: +91-9588842361



IT-2013, Ramchandrapura Industrial Area,  
Sitapura Extension, Jaipur-302022, India.



info@tesca.in  
www.tescaglobal.com