

**Specification:**

Use this ignition spark tester to check the condition of the ignition system at each cylinder. The spark tester connects between the spark plug and spark plug wire to troubleshoot dirty spark plug connections, defective points and bad cables or connections. Connects in seconds.

Troubleshoot dirty spark plug connections, defective points, bad cables or connections

Bulb flashes to indicate ignition or fuel delivery problem

Connects between spark plug and plug wire

Works on all ignition systems with non-recessed spark plugs including distributorless ignition systems (d.i.s)

Note: Specifications are subject to change, Photos shown above are Indicative, Actual Product can Vary.

TESCA TECHNOLOGIES PVT. LTD.

IT-2013, Ramchandrapura Industrial Area, Sitapura Extension, Jaipur-302029, Rajasthan, India.

Ph/ Fax: 91-141-2771791, 2771792; Email: info@tesca.in, tesca.technologies@gmail.com

Website: www.tesca.in